



## INSTALLATION INSTRUCTIONS

### SB4 PET SCREEN MODEL

*Congratulations on your purchase of the SB4 Pet Screen Door by Security Boss.  
The following is a step by step guide for installing your Security Boss product.*

#### **A SAFETY REMINDER!**

**Always wear eye protection and gloves when appropriate.**

#### **Section A: Door Installation**

**Step 1:** Be sure that you have ordered the correct size door for your pet. For long term use it is best to size the pet door so that the pivot point of the door is about 2 inches higher than your pet's shoulders. The resulting bottom of the opening should be a comfortable step over height.

**Step 2:** Check the package you received to make sure that it contains all the necessary parts.

#### **Complete Kit includes:**

Instructions

MaxSeal SB4 Pet Screen Door Model (with or without blocking panel)

1-1/4" #6 Phillips Head Screws

7/64" drill bit

#### **Tools Needed:**

Saw (Reciprocating or Jigsaw)

Pencil

Electric Drill

(Drill Bit large enough to create a "start" hole for the saw)

Level

Caulk

Phillips Head Screw driver

**Step 3:** Find a suitable area for your door mount model. Door models are available with an optional blocking panel that lifts out vertically. Make sure there is adequate room for removal of this Panel.

**Step 4:** Typically the SB4 Pet Screen door is framed in using standard structural lanai extrusions to create a Rough Opening sized appropriately for the actual door dimensions shown in the chart below. The thickness of the Lanai extrusions cannot exceed 2” from interior to exterior.

*You May also use the following rough-cut dimensions below:*

<b>Rough-Cut Dimensions</b> Based on door sizes	
<b>Size</b> (wxh)	<b>Rough Cut Required</b> (wxh)
<i>Medium</i> (9 x 12")	11" x 13 11/16"
<i>Large</i> (11 x 16")	13" x 17 11/16"
<i>Tall</i> (11 x 20")	13" x 21 11/16"
<i>Wide Tall</i> (15 x 20")	17" x 21 11/16"
<i>Mammoth</i> (15 x 24")	17" x 25 11/16"
<i>The above measurements are exact dimensions, you may add slightly depending on the accuracy of your cut.</i>	

**Step 5:** Separate the Interior and exterior door frames.

**Step 6:** Put the inner frame into the rough opening in the lanai framing. Snap the outside frame into MaxSeal door and sleeve the pet door frame together.

**Step 7:** Using the pre-drilled pilot holes and supplied drill bit, drill and insert one screw. Make sure the door is level. When level, tighten the inserted screw. Affix remaining screws into place using the pilot holes as guides

**Step 8:** Once the pet door is installed you can fill any gaps or seal the edges with caulking if desired.

## **MAINTAINENCE:**

Replacement pile weather stripping for the swinging screen is available for purchase as a screen maintenance kit through [www.securitybosspetdoors.com](http://www.securitybosspetdoors.com) and [www.moorepet.com](http://www.moorepet.com).

## **DISCLAIMER:**

### **Child Safety:**

Security Boss Manufacturing, LLC., recommends that households with small children need to exercise proper judgment with leaving their children unattended in any area with a pet door.

### **Installation:**

We recommend that any consumer that installs their own pet door wear eye protection and be familiar with the construction procedures and tools of installing a pet door.

### **Magnets:**

Virtually all doors use magnets for the activation of the pet door as well as in the sealing of the flaps. Customers with certain medical devices, for example; Pace Maker patients, should consult their physician.

If you have any questions or are unclear about these safety statements please call our Online Authorized Distributor: MoorePet Supplies, at 1-800-829-7876.