



Replacement Pile Brush Weather Seal Instructions

A SAFETY REMINDER!

Always wear eye protection and gloves when appropriate.

1. Be sure that you have the correct number of pile weather-stripping pieces for your particular door before removing the existing pieces.
2. Match the lengths of the new weather-stripping to the pieces within your door. Once you have determined where each of the new weather-stripping pieces will go, begin the install as follows:
3. Using a flat blade screwdriver from the backside of the frame, gently pry out the magnet assembly from the frame.
4. Once the magnets are out, gently slide the plastic "T" shape at the bottom of the weather-stripping into the pile weather-stripping extrusion.
5. Be sure to slide the vertical pieces into the extrusions first, followed by the bottom horizontal pieces.
6. Test fit all of the pile pieces into position before trimming any excess weather-stripping or replacing the magnets.
7. Once all weather-stripping has been put into the frame, trim any weather-stripping that extends into the area vacated by the magnet.
8. Once complete. Replace magnet assembly.