



Dear Sir or Madam:

Thank you for purchasing a Security Boss® Manufacturing, LLC., Kennel Clad™ Swing Kennel Door. Please follow these directions for installing your new External Kennel Door.

Security Boss® Kennel Clad™ Swing Kennel doors are intended to be installed over existing kennel opening passages. If you do not currently have an opening, be sure to follow local building codes in cutting and framing your specific application.

Installing the External Kennel Clad™ Swing Kennel Door in wood, drywall, or masonry:

1. Position frame on the exterior side of the pet opening. Be sure the opening in which the Frame is being put into is square and plumb. If the frame is not mounted squarely in the opening, the door will not perform to its fullest potential. Since the frame has been built to your custom sized opening, there should very little play or movement of the frame within the kennel opening. Remove any excess movement using blocking and shims.
2. Level the frame at the top of the kennel opening. Attachment of the frame to the wall is through the mounting flange. This is the fin that telescopes into the kennel opening passage. Attach the top of the frame to the wood, drywall, or masonry using the appropriate fasteners.
3. Once the frame is attached to the wall on the top side, verify the vertical sides are square with the top and ground using a level. It is important that both vertical sides are parallel to each other and square with the top to ensure the swing panel sits squarely within the frame. Shim the frame at the mounting flange as necessary to accomplish a proper fit.
4. Once the frame is secured to the wall, caulk or seal the frame to the wall along the exterior frame perimeter.
5. Check the operation of the swing panel in the opening. Movement of the swing panel should be unhindered. Wipe down the surface of the frame and swing panel after installation.
6. Your External Kennel Flap door is now installed.

MAINTENANCE:

The Security Boss® Manufacturing, LLC Kennel Clad™ Swing Kennel doors are built to give years of durable service. The pile weather-stripping is replaceable should it need replacement. The method to replacing the weather-stripping is as follows:

1. The weather stripping on the door is held in place by sections of aluminum weather-stripping holder. The **ACCESS POINTS** for replacing the pile are located in the center of the sides, bottom and top of the door...see diagram. This hole is used to remove the existing weather stripping from that section of weather-stripping holder as well as install the new material.



2. To remove the weather-stripping, use a small diameter hair pin (Bobby Pin) to get under the plastic backing of the weather-stripping. Pry the material out of the hole, and remove the old pile material. Retain the old weather-stripping sections for cutting the new material to the proper length.
3. Insert the new pile material by threading the plastic T-backing of the weather-stripping into the *Access Point* hole in the section of aluminum holder
4. Next thread the opposite end of the weather-stripping into the same hole going the opposite direction. Slowly pull the weather-stripping into the aluminum holder until evenly inserted.
5. Repeat steps 2, 3 and 4 until all sections are replaced.

DISCLAIMER:

Child Safety:

Security Boss® Manufacturing, LLC., recommends that households with small children need to exercise proper judgment with leaving their children unattended in any area with a pet door. Pet Doors come with locking panels and locking devices, using these devices

minimizes any risk, but does not replace proper parental supervision.

Installation:

We recommend that any consumer that installs their own pet door wear eye protection and be familiar with the construction procedures and tools of installing a pet door.

Magnets:

Virtually all doors use magnets for the activation of the pet door as well as in the sealing of the flaps. Customers with certain medical devices, for example; **Pace Maker patients, should consult their physician.**

If you have any questions or are unclear about these safety statements please call our Distributor: Moore Pet Supplies, at 1-800-829-7876.